

ECONOMY WALK IN DOOR INSTALLATION INSTRUCTIONS

All door cartons include the manufacturer's instruction manual. We recommend utilizing the manufacture's instructions. The following instructions are to be used as supplementary instructions only.

NOTE: DO NOT REMOVE DOOR SHIMS PRIOR TO INSTALLATION. *The door panel has been centered in the outer casing by three shims, located at the lock bolt and one on top and bottom of door panel on the latch side*

Step 1: In the rough opening, center the pre-hung door unit. Do not open the door. Level threshold and ensure jambs are plumb and squared to the header. Furthermore, between the casing and building post, shim the door without putting any undue force on the casing and causing it to move from its natural state.

Step 2: To mount the door jambs, fasten # 10 x 2 ½" pan head fasteners in the holes provided (fasteners not included). If desired, the frame may be caulked between the building frame and the nailing flange.

Step 3: Open the door and remove the shims. Then with the door in a wide open position, install one # 10 x 2 ½" pan head fastener in each hinge leaf.

Step 4: The door must be open to install the lockset. Please install lockset as per manufacturer's direction (found with in lockset box).

OPTION:

(1) Locksets

Various types of locksets available, please contact your local dealer for additional information.

Please follow manufacturer's installation instructions, as included in the lockset box.